

## **Tyrolsport Rear Subframe Deadset Kit**



**Congratulations on your new purchase.  
Kit Contents**

**4 New OEM replacement bolts  
4 bolt head locating collars  
4 subframe to chassis locating collars**

**This Kit is designed to positively locate your rear subframe. We recommend getting an alignment after installation of this kit.**

**This Procedure is very similar to installing our front deadset kit.**

Lift or jack up your vehicle and secure the vehicle on jack stands or a lift.

Using a floor jack or transmission jack support the center of the rear subframe and remove and discard the four subframe to chassis bolts.

Slowly lower the subframe to allow access between the rear subframe and chassis; about a half inch just like the front subframe installation.

Install the new bolts with the collars

**AWD shown**  
**Chassis to subframe side**



Tyrolsport - MK5/6 Golf R/R32

**Bolt to subframe side**



Tyrolsport - MK5/6 Golf R/R32

Gradually tighten all 4 subframe bolts in a diagonal pattern; Similar to tightening your wheel lugs.

**Torque Spec:**  
**Torque all 4 bolts to 90nm + 90°**

Go for a test drive and enjoy your more sound rear subframe.

If you have any questions about this install please send us an email: [info@tyrolsport.com](mailto:info@tyrolsport.com)  
or give our engineering department a call at 718.386.4604